

## APPLICATION

---

Read all instructions thoroughly before installation.

1. Clean surface of any dust, dirt, mildew, oil and other foreign substance. (For existing applications remove all old caulking before applying new caulk, clean area with a mild solution of bleach and water.)
2. Make sure area is dry before applying caulk.
3. Apply masking tape to both sides of the joint for a clean straight bead.
4. Take cap off and cut nozzle to desired bead thickness and puncture the foil seal inside the nozzle.
5. Tool Caulking within 5-10 minutes of application.
6. Remove masking tape
7. Excess may be cleaned up with mineral spirits or denatured alcohol before caulk begins to skin over

## CURE TIME

---

Light use in 3-5 days, full cure 14-28 days depending on temperature, humidity and thickness of application.

## LIMITATIONS

---

- Test on small area when working with porous materials to verify results are non-staining
- Product is moisture curing, allow exposure to air during the curing process
- Not intended for constant immersion
- Apply to joint between 40°F and 100°F
- Not for use for structural glazing
- For joints deeper than ½" use a closed cell backer rod.
- Ultra Performance Caulk is custom color matched, a compositional color difference may appear

## CLEANING & MAINTENANCE

---

Fully cured joint should be cleaned with a neutral pH cleaner, such as Colorfast Citrus Cleaner.

## SHELF LIFE

---

6-12 Months depending on storage conditions

## CAUTIONS

---

Consult MSDS

## TECHNICAL SERVICES

---

For technical assistance contact Colorfast Technical Services at 800-400-2488 or visit [www.colorfastind.com](http://www.colorfastind.com)



Colorfast Industries Inc  
912 W Highway 67  
Alvarado, TX 7600