



Laminate Seam Adhesive & Filler Epoxy Formula

- ✓ Water Clean-up
- ✓ Water Proof
- ✓ Chemical Resistance

1 Fl. Oz.

DIRECTIONS: Surface should be clean and dry, free of dust, grease or oil. Cut off tip of nossels with a sharp blade. Depress plunger to dispense equal parts of resin and hardener. Mix thoroughly with polished putty knife. Apply using putty knife for filling seams, For seam adhesive, wipe joint area with damp rag to remove any dust and to aid in final adjustment to joint height. Use small paint brush applying to both surfaces to be bonded together. Wipe off any excess with damp rag or sponge. Sets in 1-2 hours, final cure in 24-72 hours depending on temperature. After use, wipe off nossels and apply cap firmly. Note that cap fits one way only, look for slot on cap and tab on nossel.

CAUTION: Skin and eye irritant. Harmful if swallowed. Contains epoxy and amine resins. Refer to MSDS for more detailed health and safety information.

FIRST AID: Avoid contact with skin and eyes. Wash with soap and water after skin contact. Flush eyes with water. If swallowed do not induce vomiting. Call your physician or local poison control center immediately.

As with all chemicals, **keep out of reach of children.**

ColorFast Industries, Inc. Colton CA

www.colorfastind.com